



Welcome to your New TV

KEEP CALM
STAY CONNECTED

EVO DEVICE SETUP

00 TABLE OF CONTENTS

Things You Will Need	2
About the Remote Control.....	3
Connecting the Device.....	4
Pairing the Remote.....	4
Quick Set-Up	5
Setting Up the TiVO Remote to Your TV.....	7
Setting Up the TiVO Remote to External Audio.....	8
Signing In to GPC iTV	8

01 THINGS YOU WILL NEED

- Your managed streaming device, remote and power supply
- Your TV set
- HDMI cable (for EVO Force-1 set-top box only)
- Wi-Fi network name and password
- Google Account login, if available
- GPC iTV login ID and password


02 ABOUT THE REMOTE CONTROL



03 CONNECTING THE DEVICE


EVO Force 1 Streaming Device

1. Connect the included HDMI cable to the EVO Force 1 box.
2. Connect the other end of the HDMI cable to an HDMI port on your TV.
3. Connect the EVO Force 1 box to a power source using the power adapter. We suggest using a surge protector.
4. Turn on your TV and change the HDMI input until you see the screen to pair the TiVO remote. Not seeing that screen? Try a different HDMI input.




EVO Fuse 4K Streaming Device

1. Plug the EVO Fuse 4K device directly into an HDMI port on your TV. **No HDMI cable is required.**
2. Connect the included USB power cable to the device.
3. Connect the other end of the USB cable to either the included USB power adapter or an available USB port on your TV, if it provides sufficient power.
4. Turn on your TV and change the HDMI input until you see the screen to pair the TiVO remote. Not seeing that screen? Try a different HDMI input.



04 PAIRING THE REMOTE

1. Insert the included batteries into the TiVo remote.




2. To begin the pairing process, **press and release the TiVo button**. The LED light will flash amber while pairing.
3. If the remote has been paired previously, **press and hold the TiVo button and the Back button** until the LED light is solid red, then release. The LED should then begin flashing amber. **Press the TiVo button** to pair the remote.


05 QUICK SET-UP

1. Once the remote is paired with the device, a **Welcome** message will appear on your TV. You can now continue the rest of the set-up. Start by selecting a language to proceed to the next step.


2. For Android smartphone users, **select Continue** to easily transfer your phone's Wi-Fi network and Google Account to your TV. For non-Android users, choose **Skip**. Press **OK**.




3. Select the name of your Wi-Fi network from the list on the screen. If asked, enter your Wi-Fi network password.




4. Select **Sign In** to sign into your Google Account, or choose **Skip** if you do not have or want to sign in with Google. Note: If you wish to install additional applications on the EVO device, you will need a Google Account.



5. Follow the instructions on the the next few screens to:
 - a. Review and accept the terms of service and privacy policy
 - b. Select which Google Services you care to activate on your device
 - c. Allow Google Assistant to search across all TV apps on the device using the Voice Search (Google Account sign-in required)
 - d. Receive personal recommendations on the device
 - e. Receive email notifications on the latest Google Assistant features.
 - f. Name your device. We recommend naming the device to indicate where it is located at the premise.




6. If you do not want to install YouTube Kids or Twitch, **deselect them and click Continue**. The other apps are mandatory. You can add additional apps back later on also.




7. Click the **OK button** to cycle through the next section.

06 SETTING UP THE TIVO REMOTE TO YOUR TV


1. Select **Next**.
2. Select the brand of your TV from the list. If the brand is not listed, select **Other** and type in your TV brand to select the checkmark. Select your TV from the list.



3. Click the **OK** button on the remote to begin testing and watch for the TV volume to increase on its own.



- a. Click **Try Again** if you missed it
 - b. Click **Yes** if the volume did increase
 - c. Click **No** if nothing happened; if the volume does not change after about five attempts, you will be prompted to go through steps 1-3 again until the remote is paired
4. You will see this screen once you have successfully paired your TiVo remote to your TV. Test it out by powering off the TV, muting the volume and lowering the volume.



07 SETTING UP THE TIVO REMOTE TO EXTERNAL AUDIO

1. Optional: If you have a sound bar or another type of external audio device, click Next.
2. Click the **OK** button on the remote to begin testing, then press the **Volume Up** button to see if the volume does increase.
 - a. Click **Try Again** if you missed it
 - b. Click **Yes** if the volume did increase
 - c. Click **No** if nothing changed to repeat the process until it does work

08 SIGNING IN TO GPC iTV

1. Enter your GPC iTV log-in credentials.



Enjoy your New TV Service

CONTACT US

Email: contactus@gpcom.com

Phone: 888-343-8014

